


American DJ® LED Color Tube

Thank you for purchasing the LED Color Tube by American DJ®. Please read the user instructions before using your new LED Color Tube.



Controls and Functions:

1. Brightness/Speed Increase - This button will increase the brightness of the selected color or increase the speed of the strobe, flash, or fade.
2. Brightness/Speed Decrease - This button will decrease the brightness of the selected color or decrease the speed of the strobe, flash, fade, or smooth.
3. LED's Off - Turns the LED's off.
4. LED's On - Turns the LED's on.
5. Color Selection - Select one of 16 colors to remain static or strobe.
6. Flash - This function makes the fixture to scroll through the colors automatically. You can control the speed of the scroll using the speed increase and decrease buttons.
7. Strobe - This function activates the strobe effect. You can only strobe one of the 15 colors, plus white. You can control the speed of the strobe using the speed increase and decrease buttons.
8. Fade - This function makes the fixture fade in and out of the different colors automatically. You can control the speed of the fade using the speed increase and decrease buttons.
9. Smooth (Color Flow) - This activates a color flow program. You can control the speed of the color flow using the speed increase and decrease buttons.

| | |
|--------------------|------------------------------------|
| LED Color Tube | |
| Specifications: | |
| Power Supply: | 12V DC |
| LEDs: | 96 (32 Red, 32 Green, and 32 Blue) |
| Power Consumption: | 6W |
| Weight: | 2 lbs/1Kgs |
| Dimensions: | 40" x 2" x 2" |

Customer Support: American DJ® provides a customer support line, to provide set up help and to answer any question should you encounter problems during your set up or initial operation. You may also visit us on the web at www.americandj.eu for any comments or suggestions. For service related issue please contact American DJ®. Service Hours are Monday through Friday 9:00 a.m. to 5:00 p.m. central Europe Time.

Fax: 0031455468599

E-mail: service@americandj.eu

Warning! To prevent or reduce the risk of electrical shock or fire, do not expose this unit to rain or moisture.

Caution! There are no user serviceable parts inside this unit. Do not attempt any repairs yourself, doing so will void your manufacturer's warranty. In the unlikely event your unit may require service please contact your nearest American DJ dealer.

Do not discard the shipping carton in the trash. Please recycle when ever possible.